

					,						,										
	BCI Group Size	Model	1-hr Rate	2-hr Rate	5-hr Rate		10-hr Rate						Standard Terminal Type	HOURS	MINUTES @ 75 AMPS	@	@	with		Height	wet Weight Lbs (kg)
Γ	903	US L16E XC2	193	223	270	281	312	360	381	391	400	6	Large "L"	360	198	287	795	10 7/10	7 1/0	16 2/4	104 (47)
Γ	903	US L16 XC2	220	251	297	307	337	385	408	419	428	6	Large "L"	385	225	322	865	12-7/16			110 (50)
7	903	US L16HC XC2	239	272	323	335	368	420	445	457	467	6	Large "L"	420	250	358	965	(315)	(181)	(425)	118 (54)



VENT CAP OPTIONS




CHARGING INSTRUCTIONS:


Following is the charging recommendation and charging profile using 2 stage chargers for US Battery deep cycle products. *Equalization and float charge modes are not considered to be one of the stages in a charging profile. **Bulk Charge** 1. Constant current @~10% of C/20 Ah in amps to 2.45+/-0.05 volts per cell (e.g. 7.35 volts +/-0.15 volts per 6 volt battery) 2. **Absorption Charge** Constant voltage (2.45+/-0.05 vpc) to 3% of C/20 Ah in amps then hold for 2-3 hours and terminate charge Charge termination can be by maximum time (2-4 hr) or dV/dt (4 mv/cell per hour) (Optional Float Charge) Constant voltage 2.17 vpc (6.51 volts per 6 volt battery) for unlimited time • **Equalization Charge** Constant voltage (2.55+/-0.05 vpc) extended for 1-3 hours after normal charge cycle (repeat every 30 days) Notes: Charge time from full discharge is 9-12 hours. Absorption charge time is determined by the battery but will usually be ~3 hours at 2.45 volts per cell. Float time is unlimited at 2.17 volts per cell. Specific gravity at full charge is 1.270 minimum reduce the voltage by 0.028 Volts per cell for every 10°F above 80°F, increase by the same Battery temperature adjustment: amount for temperatures below 80°F. Deep cycle batteries need to be equalized periodically. Equalizing is an extended, low current charge performed after the normal charge cycle. This extra charge helps keep all cells in balance. Actively used batteries should be equalized once per month. Manually timed chargers should have the charge time extended approximately 3 hours. Automatically controlled chargers should be unplugged and reconnected after completing a charge.




US L16E XC2, US L16 XC2, US L16HC XC2








EXPECTED LIFE CYCLES VS. DOD (XC, XC2 & AGM)






DATA SHEET Deep Cycle 6 -Volt

U.S. Battery Recommended Terminal Torque and Connection Hardware										
U.S. Battery Terminal Type	Recommended Torque (in-lb)	Recommended Torque (ft-lb)	Recommended Connection Hardware							
UTL	95-105	7.9-8.8	¹ SS Hexnut with Lock Washer							
Molded-In UTL	95-105	7.9-8.8	¹ SS Hexnut with Lock Washer							
UT	95-105	7.9-8.8	¹ SS Hexnut with Lock Washer							
Flat Block	95-105	7.9-8.8	¹ SS Hexnut with Lock Washer							
Dual	95-105	7.9-8.8	^{1/6} SS Hexnut with Lock Washer							
DC Marine	95-105	7.9-8.8	² SS Hexnut with Lock Washer							
Off-Set "S"	100-120	8.3-10	³ Zn or SS Bolt w/Hexnut & Lock Washe							
Flag	100-120	8.3-10	⁴ Zn or SS Bolt w/Hexnut & Lock Washe							
Large "L"	100-120	8.3-10.0	⁴ Zn or SS Bolt w/Hexnut & Lock Washe							
Small "L"	100-120	8.3-10.0	⁴ Zn or SS Bolt w/Hexnut & Lock Washe							
Bus Lug	120-180	10.0-15.0	⁵ SS Hexnut with Lock Washer							
SAE	50-70	4.2-5.8	⁶ No Hardware Supplied							

Proper connection is to position a lock washer between the nut and the connector (never between the connector and lead terminal) and apply the recommended torque or enough torque to completely compress the lock washer without deforming the lead terminal

¹Stainless Steel Hexnut with Stainless Steel Split-Ring Lock Washer (5/16" Positive & Negative) ²Stainless Steel Hexnut with Stainless Steel Split-Ring Lock Washer (3/8" Positive & 5/16" Negative) ³Square-Head, SS or Zinc-Plated Bolt with SS or Zinc-Plated Hexnut & Split-Ring Lock Washer ⁴Square-Head or Hex-Head, SS or Zinc-Plated Bolt with SS or Zinc-Plated Hexnut & Split-Ring Lock Washer ⁵Stainless Steel Hexnut with SS Split-Ring Lock Washer (1/2" Positive or 3/8" Positive & 3/8" Negative) ⁶No Hardware Supplied - Application Uses SAE Clamp for Positive & Negative Tapered Post Note: The use of flanged nuts and other types of nuts with captive washers or other hardware not listed

above is not recommended by US Battery and their use may void the battery warranty.



U.S. Battery Operating Temperature Guidelines

For charging, we recommend staying within 0°F to 120°F (-18 to 49°C) to avoid charging frozen batteries at low temperature or going into thermal runaway at high temperature.

For discharging, we recommend -20°F to 120°F (-29 to 49°C). Batteries discharged at temperatures below 32°F (0°C) should be recharged immediately to avoid freezing.

Batteries discharged at temperatures above 120°F (49°C) should be allowed to cool before recharging.

Extreme temperatures can substantially affect battery performance and charging. Cold reduces battery capacity and retards charging. Heat increases water usage and can result in overcharging. Very high temperatures can cause "thermal run-away" which may lead to an explosion or fire. If extreme temperature is an unavoidable part of an application, consult a battery/charger specialist about ways to deal with the problem.

Data references within this publication are nominal and should not be considered or construed as maximum or minimum values for specifications or for final design. Data for this product type and model may varyfrom what is shown in this publication, and U.S. Battery Mfg., Co. makes Nowarranties, expressed or implied based on the data within this publication.

©2019 U.S. Battery Mfg., Co. All rights reserved. U.S Battery is not liable for damages that may occur from any information provided in or omitted from this publication, under any circumstances. U.S. Battery Mfg., Co. reserves the right to make changes or adjustments to this publication at any time without notices or obligations.

